m100 Blue
mrHandsfree® Beat

USER'S MANUAL

GB NL FR D
E CZ SK DK EST

BLUETOOTH®
WIRELESS STEREO SPEAKER



DECLARATION OF CONFORMITY

We, the undersigned

Company:	TE-GROUP nv
Address:	Kapelsestraat 61, 2950 Kapellen - BELGIUM

declare, that the following equipment:

Product Name:	BLUE BEAT M100
Product Type:	Bluetooth® Stereo Speaker

Conforms with the requirements of European Council Directive 99/5/EC

CE

Joseph van Oosterum, CEO TE Group NV, November 2011

----------QRG/BLUE BEAT/10-11/V01----------

ILLUSTRATIONS

ILLUSTRATION I



ILLUSTRATION II



PACKAGE CONTENTS & PARTS

GB

SEE ILLUSTRATION I

1. ON/OFF Power Switch
2. LED Indicator Light
3. Audio socket (AUX)
4. USB charging socket (DC5V)
5. Music buttons
6. Fold-out feet
7. Battery compartment cover (1000 mAH 3.7V rechargeable lithium polymer battery inside)
8. USB cable (for charging)
9. 3.5 mm audio jack cable (for NON-Bluetooth® devices)

! Please do not use any other chargers, cables or battery than the ones included in this package!

PLACEMENT

SEE ILLUSTRATION II

The Blue BEAT has 2 small feet (6) that can be folded out to provide balance and add stability when placing it on any kind of surface.

CHARGING THE BATTERY

1. Plug the USB cable (8) into the USB charging socket (4) of the Blue BEAT.
2. Plug the other end of the USB cable (8) into your computer or USB charger.
3. The red LED indicator (2) on the Blue BEAT will light up and your Blue BEAT will start charging. Charging time will take max. 3 hours.
   ! Red LED indicator (2) remains on as long as Blue Beat is connected by USB cable!
4. The Blue BEAT's battery offers up to 10 hours music time. Blue LED indicator (2) will flash alternately as soon as Blue BEAT is switched ON. Music time may vary from usage (volume).

TURNING BLUE BEAT ON / OFF

To turn the Blue BEAT ON:

Slide the Power Switch (1) to the 'ON' position. The blue LED indicator (2) will start flashing and you will hear a melody indicating that the Blue BEAT is entering pairing mode and is starting to search for available Bluetooth® devices.

To turn the Blue BEAT OFF:

Slide the Power Switch (1) to the 'OFF' position. The Blue LED indicator (2) will turn off indicating that the Blue BEAT is now turned off.

PAIRING THE BLUE BEAT WITH A BLUETOOTH® MUSIC DEVICE (*)

You are required to pair the Blue BEAT with your **Bluetooth® music device** once before using it. Slide the Power Switch (1) to the 'ON' position. The blue LED indicator (2) will start flashing and you will hear a melody indicating that the Blue BEAT is entering pairing mode and is starting to search for available Bluetooth® devices. The Blue BEAT is now ready for pairing → Let your Bluetooth® music device search for other Bluetooth® devices (please refer to the manual of your Bluetooth® music device for more information). → Select the **Blue BEAT** out of the list with found devices on your Bluetooth® music device and enter PIN code **0000*** to pair both devices. You will hear a short beep. → The blue LED indicator (2) will flash every 4 seconds.

Once the Blue BEAT is successfully paired, you can use it to listen to your favorite music wirelessly in stereo. **PIN code is usually not required for Bluetooth® 2.1 mobile phones*

Note!

The Blue BEAT will automatically reconnect to the last connected device when the Blue BEAT is turned ON again.

In case your Bluetooth® music device does NOT reconnect automatically with the Blue BEAT you can:

- Reconnect manually with your Bluetooth® music device (please refer to the manual of your Bluetooth® music device for more information).
- Reconnect manually by pressing ⏭VOL+ button once on the Blue BEAT.

(*) Bluetooth® music devices are all Bluetooth® stereo music devices that support Bluetooth® A2DP profile (e.g. iPhone™, iPad®, music phones, laptops, Android® phones & tablets, ...) .

MUSIC BUTTON OPERATION

Music can be controlled from your Bluetooth® music device or by using the Blue BEAT's music buttons (5):

BUTTON	HOW?
⏭VOL+	**- PRESS ONCE TO PLAY THE MUSIC** **- PRESS ONCE TO PAUSE THE MUSIC** **- PRESS ONCE FOR MANUAL RECONNECTION BETWEEN BLUE BEAT AND BLUETOOTH® MUSIC DEVICE**
⏯	**- PRESS ONCE TO JUMP TO NEXT SONG** **- PRESS AND HOLD TO INCREASE VOLUME**
⏮VOL-	**- PRESS ONCE TO JUMP TO PREVIOUS SONG** **- PRESS AND HOLD TO DECREASE VOLUME**

CONNECTING THE BLUE BEAT WITH A NON-BLUETOOTH® MUSIC DEVICE (**)

You can also play music from a **NON-Bluetooth® music device** on the Blue BEAT by using the 3.5 mm jack cable (9). Plug the jack cable (9) into the audio socket (3) of the Blue BEAT. Plug the other end of the jack cable (9) into the audio socket of your music device.

Note!

When playing music from a device connected to the Blue BEAT using the jack cable (9), all music functions (play/pause /FWD/BWD/VOL+/VOL-) need to be operated from the music device, NOT from the Blue BEAT's music buttons (5).

(**) NON-Bluetooth® music devices are all music devices provided with a 3.5 mm jack socket (e.g. a regular MP3 player).

Due to many slight differences in music devices and phones, above mentioned operations may vary!

GUARANTEE

Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of two (2) years from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: www.mrhandsfree.com.